

evii STP-045U

Quick Guide User Manual



Warnings

Not following these simple guidelines may be dangerous or illegal. Read the complete user guide for further information.

TURN ON SAFELY

Do not turn on the phone when wireless phone is prohibited or when it may cause interference or danger.

ROAD SAFETY

Obey all road safety laws. Always use both of your hands to operate the vehicle while driving.

INTERFERENCE

All wireless phones may be sensitive to interference, which may affect performance.

TURN OFF IN HOSPITALS

Follow all restrictions. Turn off the phone near medical equipment.

TURN OFF IN FLIGHT

Follow all restrictions. Wireless devices can cause interference in aircraft.

TURN OFF WHEN REFUELING

Do not use the phone at/near refueling stations. Do not use near fuel or chemicals.

USE SENSIBLY

Only qualified personnel may install or repair this product.

ENHANCEMENTS AND BATTERIES

Use only appropriate enhancements and batteries. Do not connect incompatible products.

WATER-RESISTANCE

Your phone is not water-resistant. Keep it dry.

BACKUP COPIES

Remember to make back-up copies or keep a written record of all important information stored in your phone.

CONNECTING TO OTHER DEVICES

When connecting to any external device, read its user guide for detailed safety instructions. Do not connect with incompatible products.

Content

Your Phone.....	6
Keypad descriptions	7
Input methods.....	7
Using for the first time.....	8
Charging the battery	8
Using the touchscreen.....	9
Making a Call.....	9
Answering a Call.....	10
Emergency Service.....	10
1. Backup and Restore.....	11
2. Browser.....	11
3. Calculator.....	11
4. Calendar	11
5. Camera	11
6. Clock.....	11
7. Downloads	12
8. Email.....	12
9. File Manager	12
10. FM Radio	12
11. Gallery.....	13
12. Messaging	13
13. Movie Studio	13
14. Music	13
15. ToDo	13
16. People.....	13
17. Phone	14

18. Settings.....	14
19. Sound Recorder	15
Widgets	16
Accessories	16
Care and Maintenance	16

Your Phone



Keypad descriptions

Key	Description
Power Button (Right side)	Press the button: During a few seconds to turn on the phone; Once to lock the screen; During a few seconds to display phone options.
Back Key	Press the key to return to previous menu.
Home Key	Press the key to return to standby mode. Press the key a few seconds to show list of recent activities.
Options Key	Press the key to display Options menu.
Volume Buttons (Left side)	Press the buttons to adjust the volume of the ringtone, calls, music player, video player, and radio.

Input methods

Your phone has the built-in input method. Press the Messaging key icon in standby screen mode to edit messages. In edit mode, press the Options menu to display **Input Settings** to define the language and Android keyboard settings.

Word input

Use the on-screen keypad to enter letters.

Number input

Press the Numbers key to display the numbers to input.

Symbol input

Press the punctuation or smiley keys to show symbols list.

Using for the first time

Installing SD Card, SIM Card and Battery

Your network plug-in SIM (Subscriber Identity Module) card contains phone numbers and available services. Additional phone numbers and personal information can be stored.

Warning: Do not bend or scratch the SIM card, or let it come into contact with static electricity, dust or water. Keep all SIM cards out of the reach of children.

Note: Keep the SIM card chip contacts face down. Insert the SIM card into the indicated slot.

Removing the SD Card, SIM Card and Battery

Note: If the phone is turned on, press the Power button for about 3 seconds to display the Phone Options, select **Power off** and press **OK** to turn off the phone. Then remove the battery, SIM card and SD card.

Do not insert or remove the SD card while the phone is in boot state to avoid damage to the file system in the phone.

Charging the battery

1. Before charging, check the battery slot to ensure the battery has been inserted correctly.
2. Plug one end of the charger into phone.
3. Connect another end of the charger to the socket.
4. Charging will start, whether the phone is turned on or off. When the battery icon on the screen starts animating, charging is in effect. When the icon is full and stops animating, charging is complete.
5. Unplug the charger from the socket.
6. Disconnect the charger from the phone.

Using the touchscreen

- Pressing the screen with finger selects the desired option or to start running an application.
- Pressing the screen for a few seconds in the current interface, or on an icon, or in an input area, displays other available options in that specific interface.
- Sliding the finger on the screen horizontally, either in standby mode or in the main menu screen, allows navigation from side to side of the page.
- Pressing an item on the screen for a few seconds allows for dragging it to another location on the screen. For example, an icon can be dragged from the main menu screen to the standby mode screen.

Making a Call

1. In standby mode or in the main menu, press the dial key icon to enter the dial panel, press the numbers on screen to enter the phone number.
2. Press the Dial key icon at the bottom and select the desired SIM card to dial the number.
3. Press the End key icon to cancel the call.



- Unlock the screen if necessary.
- You can make calls through the Call log, your Contacts, or the Messages.
- During a call press the Volume Keys to adjust the volume.
- Your phone supports intelligent dial. When inputting numbers, the phone will search the corresponding contact in the phonebook or in the call log.

Answering a Call

During an incoming call you can:

- Drag the icon toward the right to answer the call.
- Drag the icon toward left to decline the call.
- Drag the icon upward to reject the call with SMS.

Emergency Service

You can call an emergency service number directly without SIM card. Different networks use different emergency numbers. Please query your network operator.

1. Backup and Restore

In this menu, you can choose to **BACKUP** and **RESTORE** applications and personal data.

2. Browser

Access WAP (Wireless Application Protocol) sites and use WAP-based services. To browse WAP pages, you must subscribe to the data service from your service provider and configure your phone's relevant settings.

Select the website list on screen or type the URL in the address bar to navigate the web.

3. Calculator

The calculator executes simple calculations. Slide the screen to the left or to the right to change between the **Basic panel** and the **Advanced panel**.

4. Calendar

In the calendar, schedules can be checked for the current month, and alarms can be set. Select one date to check all schedules for that day, or edit and delete schedules.

5. Camera

The camera app allows photos to be taken and stored. Press the **Camera** icon in main menu to enter. Press the shoot icon to take photos or the video icon to film.

Slide the icon bar at the top of screen or press the Option Key to select different functions and set parameters of the camera or video recorder.

6. Clock

In the clock interface, you can check the time and the date. Press the alarm icon to set the alarm clock or turn on/off existing alarm clocks.

Other functions include countdown, stopwatch, cities settings and night mode.

7. Downloads

Check all downloads applications.

8. Email

In **Email** send and receive emails.

Setup Email Account

Follow indicated steps on screen to setup email address and password, and press **Next**. Alternatively, **Manual setup** can be used to setup server information manually.

Checking Emails

In the **Inbox**, select the email you want to open. Select the icons at the bottom to Delete, Reply, or Add to Favorites.

Composing and Sending Emails

In the **Inbox**, select New mail icon to compose a new email message. Type in the recipient email address, the Subject, and content, and select Send icon to send the email.

Deleting email Accounts

To delete an existing email account go to general Settings, and in **ACCOUNTS**, select the account, press the Options key and select **Remove account**. Press **OK** to confirm to delete the account.

9. File Manager

Access the Phone storage and SD card.

10. FM Radio

To access **FM Radio**, select the app in the main menu, and plug in earphones. Select the Power icon to turn the radio on/off. Select the settings icon, **Search**. The phone will search available channels, saving them in the list. Select the forward/backward keys to operate the FM radio.

11. Gallery

In the Gallery, view or manage your photos and videos.

12. Messaging

Select **Messaging** in the main menu or in the standby mode to edit messages. To create a new SMS or MMS, select the New message icon in the left bottom corner, and then send it:

1. Enter recipient's number or add a number from the Contacts list.
2. Select "**Type text message**" to type message content.
3. To add a picture, audio, or video file to the message, select the "+" key. The message will automatically shift to multimedia message.
4. Select the Send icon, and select the desired SIM card.

13. Movie Studio

This application edits video clips.

14. Music

Select the **Music** icon in the main menu. Select **Artists**, **Albums**, **Songs**, or **Playlists** at the top of the screen to change category. Select an audio file to play music. Select the on screen keys to operate the audio player.

15. ToDo

Select the **ToDo** icon to save notes on the go, in the main menu. Select the pencil icon at the top to add a new note. Saved notes can be viewed and edited.

16. People

Select the **People** icon to search for contacts or select **Add new account** icon to add new contact. Selecting the Options Key various functions become available: **Delete contact**, **Contacts to display**, **Import/export** (copies the contacts from the SIM cards, the phone

storage or from the SD card, to a new location), **Accounts** (selects whether to Auto-sync app data), **Settings** (sorts list by..., or view contact names), **Share Visible Contacts** (share one or more contacts via Bluetooth, email, etc.).

17. Phone

Type the numbers of the contact in sequence, select the Dial icon and the desired SIM card. The Call log or the contact can also be selected from the icons at the top of the screen.

18. Settings

Wireless & Networks

In this menu **SIM management**, **Wi-Fi**, **Bluetooth**, **Data usage**, and **More...** (**Aeroplane mode**, **Tethering & portable hotspot**, **VPN**, **Mobile networks**, **USB Internet**) can be selected and set.

- **Wi-Fi**

Connect to a wireless high speed network.

To turn Wi-Fi on, slide the icon next to **Wi-Fi** to the right. Select **Wi-Fi** to check and access available wireless networks. If the selected network is encrypted, type in the password.

- **Bluetooth**

Bluetooth is supported, allowing for information to be exchanged wirelessly between devices, including mobile phones. Through Bluetooth, the phone can be synced with a computer, data exchanged with other Bluetooth devices, and connection made to Bluetooth earphone.

To turn Bluetooth on, slide the icon next to **Bluetooth** to the right. Before transferring data, match with other Bluetooth devices.

Device

In this menu, set Audio profiles and Display, check Storage and Battery, and manage Apps.

Personal

- **Location**

Select whether to access your location, to turn on/off GPS satellites, or whether to use Wi-Fi & mobile network location.

- **Security**

Select **SCREEN SECURITY, ENCRYPTION, SIM CARD LOCK, PASSWORDS, DEVICE ADMINISTRATION**, and **CREDENTIAL STORAGE** in this menu.

- **Language & input**

Select and set Language, **KEYBOARD & INPUT METHODS, SPEECH**, and **MOUSE/TRACK PAD**.

- **Backup & reset**

To clear all data in the phone memory, select **Factory data reset** and then **Reset phone**. Select **DRM reset** to delete all DRM licenses.

Accounts

- **Add account**

Add a new Corporate, email, or Facebook account.

System

- **Date & time**

Set time and date for the phone.

- **Scheduled power on & off**

Set when to power on/off the phone automatically.

- **Accessibility**

To set accessibility functions for the phone.

- **Developer options**

This function takes bug report, sets desktop backup password, etc.

- **About phone**

Check Status, Legal information, etc.

19. Sound Recorder

Sound record function is supported. Files can be saved with different quality settings available in the Options menu. Recorded files can be sent via Bluetooth, message or email.

Widgets

In the widgets list, accessible via Options key, widgets can be selected and dragged to the screen in standby mode.

Accessories

The following accessories are provided:

- Lithium battery
- Battery charger

Care and Maintenance

- **Battery Care**
 - Your device is powered by a rechargeable battery. When the power is weak, please charge the battery. In order to extend the lifespan of the battery, use all the battery's power before recharging.
 - Unplug the charger from the electrical socket and the device when not in use. Do not leave the battery connected to a charger more than a week. Overcharging may shorten the phone's lifespan.
 - Extreme temperatures can affect the ability of your battery to charge. In temperatures over 40°C, the battery cannot be charged.
 - Use the battery only for its intended purpose. Never use any charger or battery that is damaged.

Do not short-circuit the battery. Accidental short-circuiting can occur when a metal object such as a coin, a clip, or a pen comes into direct contact of the positive (+) and negative (-) terminals of the battery. These look like metal strips on the battery. Short-circuiting the terminals may damage the battery or the object coming into contact.

- Leaving the battery in very hot or cold places, such as in a closed car in summer or in a freezer, will reduce the capacity and lifetime of the battery. Always try to keep the battery between 15°C and 25°C.

A hot or cold battery may not function temporarily, even when the battery is fully charged.

- Battery performance is particularly limited in temperatures below freezing.
- Do not dispose of batteries in a fire! Dispose of batteries according to local government regulations. Please recycle when possible. Mobile phones are not considered organic waste.
- Mobile phone maintenance
 - Keep this device dry. Rain, humidity, and all types of liquids or moisture can contain minerals that will corrode electronic circuits. If your device does get wet, remove the battery and allow the device to dry completely before using it.
 - Do not use or store the device in dusty, dirty areas. Its moving parts and electronic components can get damaged.
 - Do not store the device in hot areas. High temperatures can shorten the lifespan of electronic devices, damage batteries, and warp or melt certain plastics.
 - Do not store the device in cold areas. When the device returns to its normal temperature, moisture can form inside the device and damage electronic circuit boards.
 - Do not attempt to open the device other than as instructed in this guide.
 - Do not drop, knock, or shake the device. Rough handling can break internal circuit boards and fine parts.
 - Do not use chemicals, cleaning solvents, or strong detergents to clean the device.
 - Do not paint the device. Paint can clog the moving parts and prevent proper operation.
 - Use only the supplied or an approved replacement antenna. Unauthorized antennae, modifications, or attachments could damage the device and may violate regulations governing radio devices.

All of the aforementioned concerns apply to your device, battery, charger, or any enhancement. If the device is not working properly, take it to the nearest authorized service facility for repair.

Caution: The manufacturer will not assume any responsibility for damages to the phone resulting from misuse or handling of the phone that does not comply with the aforementioned warnings.